


# ecostrad

INSTRUCTION MANUAL

## Ecostrad Magma HHR German Storage Heater



PLEASE READ AND SAVE THESE INSTRUCTIONS





# Symbols

## Warning



This symbol indicates a hazard with an average risk level which, if not avoided, could result in serious injury or death.

## Warning of electrical voltage



This symbol indicates danger to the life and health of persons due to electrical voltage.

## Do not cover



This symbol located on the device indicates that it is prohibited to place objects (such as towels, clothes etc.) above or directly in front of the device.

To avoid overheating and fire hazards, the device must not be covered.

## Hot surface



This symbol located on the device indicates that its surfaces are hot during and immediately after operation.

Hot surfaces should not be touched: danger of burns.

## Do not spray



This symbol located on the device indicates that it is prohibited to spray the device.

## Observe instructions in manual



This symbol located on the device indicates that instructions in the operating manual must be observed when installing and using the device.



# Contents

<b>1  </b>	<b>About the Product</b>	<b>4</b>
<b>2  </b>	<b>Warnings &amp; Precautions</b>	<b>5</b>
<b>3  </b>	<b>Technical Information</b>	<b>8</b>
<b>4  </b>	<b>Manual Operation</b>	<b>9</b>
4-1	Getting the most out of your storage heater	9
4-2	Screen and buttons	10
4-3	Operation Modes	11
4-3-1	Off mode	11
4-3-2	Fixed temperature mode	11
4-3-3	Weekly schedule mode	12
4-3-4	Boost mode	12
4-4	Device pairing	13
4-5	Keypad lock	13
4-6	Device settings	14
4-6-1	Temperature settings	14
4-6-2	Time & date settings	14
4-6-3	Program settings	15
4-6-4	Device type	16
4-6-5	Frost protection	17
4-6-6	Program resolution	17
4-6-7	Charge configuration	17
4-6-8	Units	19
4-6-9	Display settings	19
4-6-10	Beep	20
4-6-11	Control type	20
4-6-12	Open window detection	21
4-6-13	Smart start	22
4-6-14	Offset temperature	22
4-6-15	Parameters	23
4-6-16	Language	23
4-6-17	Reset	23
<b>5  </b>	<b>Warranty</b>	<b>24</b>
<b>6  </b>	<b>Disposal</b>	<b>25</b>

# 1 | About the Product

This manual describes the Ecostrad Magma HHR German Storage Heater and details how to operate the product. It is important to thoroughly review this manual before operating the product.

The accompanying installation manual details how to install the Ecostrad Magma HHR. Store the installation manual and user manual near the installed heater.

## Heat Performance

The Ecostrad Magma HHR's patented silent automatic vent system allows the storage heater to control heat release without a noisy fan.

This storage heater generates and stores heat by heating elements that are surrounded by insulated stone bricks. The stone bricks work as a thermal mass, storing the heat within the storage heater core. The heat can only escape from the insulated core when the vent opens, allowing the storage heater to release heat at specific times of day to heat your room without using additional power.

For **technical advice** or help concerning the Ecostrad Magma HHR German Storage Heater, contact the retail establishment or distributor from which the product was purchased.

## 2 | Warnings & Precautions

### READ ALL SAFETY WARNINGS AND ALL INSTRUCTIONS.

Read this manual carefully before operating or installing the storage heater. Always store the manual in the immediate vicinity of the storage heater or its site of use.

Failure to follow the warnings and instructions may result in electric shock, fire, serious injury, or all of the above. Save all warnings and instructions for future reference.

#### Warning



This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

#### Warning



Children of less than 3 years should be kept away unless continuously supervised.

Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children aged from 3 years and less than 8 years shall not plug in, regulate, or clean the appliance, or perform maintenance.

#### Warning



In order to avoid a hazard due to inadvertent re-setting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

#### Warning



In order to avoid overheating, do not cover the appliance.

## Warnings & Precautions

### READ ALL SAFETY WARNINGS AND ALL INSTRUCTIONS.

#### Warning



Some parts of this product can become very hot and cause burns. Do not touch the surface when in operation. Do not install close to curtains or other combustible materials. Particular attention should be given where children and vulnerable adults are present.

#### Warning



Do not use the device in enclosed spaces if persons are present who cannot leave the room independently and are not under constant supervision.

- Keep the power cable away from all hot parts of the appliance.
- Do not use the device if you detect damage to the mains power cable. If the supply cord is damaged, it must be replaced by the installer or a similarly qualified person to avoid a hazard.
- All repairs and servicing must be carried out by a qualified person. To avoid danger any repairs must be completed by the manufacturer, a service agent of the manufacturer or a similarly qualified person.
- Make sure that the voltage indicated on the rating plate for this appliance corresponds to your power outlet.
- The device must not be located immediately below or in front of an electrical socket outlet.
- Do not use this device in the immediate surroundings of a bath, shower, swimming pool or any other water container. Risk of electric shock.
- Do not use the device with wet or damp hands.
- No part of the appliance should be submerged in any type of liquid.
- Cleaning should be carried out using a damp cloth only. No abrasive chemicals or materials should be used.
- Never insert fingers or other objects or body parts into the device. Risk of electric shock or injury.
- Do not use any accessories with this device. Use of accessories may cause damage or danger.
- Keep the device at a minimum distance of one metre from curtains and other flammable materials.
- The device must only be installed in an upright and fixed position in accordance with national installation rules.
- The device is for indoor use only.
- Temperature differences can cause crackling and other noises in the unit. This does not indicate any failure in the radiator.
- Do not use the radiator with a programmer, timer, separate remote control system or any other device that switches the radiator on automatically, since a fire risk exists if the radiator is covered or positioned incorrectly.
- Make sure the minimum safety distances from walls and objects stated in the installation instructions are observed at all times. This is very important to prevent damage to walls, furniture and soft furnishings and to prevent the product overheating.
- Do not use the device in rooms where contact with flammable or potentially explosive materials like dust, gas or vapour cannot be avoided. If the atmosphere becomes temporarily unsafe, such as when painting or remodeling a room, the heater should not be charged and must be covered, especially at the air outlet grille.



## Warnings & Precautions

- For installation in commercial buildings (e.g. workshop, hair salon, laboratories, etc.), please contact your professional association.
- Do not use the device in rooms or environments that have a corrosive atmosphere.
- Do not operate the device when wet. If the device gets wet during cleaning, allow it to dry out before using.
- Do not expose the device to water jets.
- Do not transport the device during operation.
- Do not sit on the device.
- Do not overload the circuit used to power the device.
- Before carrying out maintenance, care or repair work on the device, ensure the power supply is switched off. Terminals may be under live voltage even if all circuit breakers have been switched off.
- Allow the device to fully cool before touching or transporting the device, or attempting maintenance work.
- The device must be placed where the switches and controllers cannot be touched by a person in a bathtub or shower. Risk of electric shock.
- If the appliance was moved and has been in use before, the thermal insulation must be checked to ensure it is still in good condition. If necessary, damaged or worn parts must be replaced. Be very careful to not damage the high performance thermal insulation when removing and mounting the heater.
- Do not use the appliance for any other purpose than the described purpose.
- Appliances which are no longer used should be disconnected immediately and the connecting cables should be cut through. Dispose of the appliance in accordance with local regulation.
- Due to the weight of the appliance, check the stability of the floor with an expert. The floor surface must be flat and even. The appliance can be placed on any kind of floor, but deformation may occur to the floor covering due to the heat and weight of the appliance. For example, flooring with PVC, parquet floor, and light coloured carpets.
- When the appliance is filled with bricks, it may sink somewhat into the pile when installed on thick-pile carpeting. For installation on thick-piled carpet, it is recommended to remove the carpet around the feet of the appliance. This creates a stable, flat, and even surface for installation.
- To prevent accidents and possible tipping of the heater, it must be fixed to the wall with safety screws, supplied with the heater. The necessary screws and plugs are found in the lower part of the switchboard in a plastic bag. Failure to fasten the appliance to the wall may result in injury or death.
- If the wall is not strong enough, a more adequate fixing material has to be used.
- The installation must be equipped with an all pole circuit breaker, allowing the power supply to be cut off to the appliance in case any maintenance is required.
- Do not place any socket in the direct proximity of the appliance.
- According to the low voltage guidelines, all existing and new installations must be equipped with an earth leakage protection device sensitive also to direct current pulses.
- This device must be installed by a licensed electrician.



### 3 | Technical Information

Model	E-MAGMA-HHR-SH-17	E-MAGMA-HHR-SH-25	E-MAGMA-HHR-SH-34
Nominal power	1700 W	2550 W	3400 W
Nominal voltage	230V 50 Hz	230V 50 Hz	230V 50 Hz
Nominal charge	13.6 kWh	20.4 kWh	27.2 kWh
Maximum nominal charge acceptance	15.5 kWh	23.2 kWh	30.9 kWh
Dimensions (mm) width x height x depth	670 x 720 x 185 mm	880 x 720 x 185 mm	1090 x 720 x 185 mm
Total weight	88 kg	127 kg	166 kg
Housing weight	24 kg	31 kg	38 kg
Number of brick pairs	4 pairs	6 pairs	8 pairs
Core weight	64 kg	96 kg	128 kg
Heating elements	2 x 850 W	3 x 850 W	4 x 850 W
Top-up heater power	500 W	750 W	750 W
IP rating	IP20	IP20	IP20
Appliance class	Class I	Class I	Class I

## 4 | Manual Operation

### 4-1 | Getting the most out of your storage heater

#### **Upon first power-on, set up the charging periods and the heating schedule**

The Ecostrad Magma HHR storage heater is equipped with smart charging technology, ensuring that the heater only uses the energy required to heat per your daily schedule.

1. Set your off-peak (charging) periods. Consult your energy provider if you aren't sure what hours of the day have the lowest rates.
2. Set your heating schedule.

The Ecostrad Magma HHR will automatically calculate how long it needs to charge to maintain your daily heating schedule, adjusting as needed to ensure no wasted energy.

#### **The charging and heating goals may conflict**


In most cases, the process of charging the storage heater will raise the room temperature to a comfortable level without requiring any additional venting.

- Due to the ambient heat from the actively charging storage heater, the room temperature could rise up to 3 °C above your set temperature during the off-peak charging time.
  - This extra heat is necessary to ensure the storage heater has sufficient heat stored to keep your room warm until the next charging period.
- If the heater is scheduled to maintain a very high heat during the off-peak charging period, the heater may take longer to charge up.
  - For a faster charge, the top-up heating element can be enabled to heat the room during off-peak periods.
  - The top-up heating element can heat the room directly, allowing it to maintain the room's temperature without slowing the rate of charge.
  - Alternatively, the heater may be set to a lower economy temperature during charging intervals.

## Manual Operation

### 4-2 | Screen and buttons

The Ecostrad Magma HHR German Storage Heater has a TFT LCD screen and 4 push-buttons to control the device:



- +** Increase temperature. Navigate (when in menu).
- Decrease temperature. Navigate (when in menu).
- ⏻ / OK** Power the heater on or off. Select option (when in menu).
- Menu / Save** Hold for 5 seconds to open settings. Go back (when in menu).
- 🔔** Press **+** or **-** to set up a boost period

Table 1 | Icons

Icon	Description
	Device is charging
	Charge percentage
	Top-up heating active
	Vent open
	Top-up heating and vent open
	Device linked with Smartbox
	Open window detection active
	Adaptive start active

## 4-3 | Operation Modes

Upon first power-on, select either **fixed temperature** or **weekly schedule** mode.

The Ecostrad Magma HHR has 4 operation modes





Figure 1 | Operation modes from left to right: off, fixed temperature, weekly schedule, boost

- To toggle between OFF and your preferred heating mode, press (⏻).
- To use boost mode, press + or – during normal operation.

### To select the preferred heating mode



1. Hold **Menu** down to enter the settings menu
  - Use +, – and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **DEVICE TYPE**
4. Select your preferred heating mode
  - **FIXED TEMPERATURE**: the target temperature is set manually
  - **WEEKLY SCHEDULE**: the heater follows a 24/7 schedule
5. Press **OK** to confirm.

### 4-3-1 | Off mode

Press (⏻) to put the device into OFF mode.

In OFF mode, the device is switched off. It does not charge and does not heat.

- If frost protection is enabled, the heater will only release heat if the room temperature drops below 3 °C.
  - Frost protection can be enabled or disabled from the settings menu.

Press (⏻) again to return to the heating mode.





Figure 2 | OFF with frost protection disabled (left), enabled (right)

### 4-3-2 | Fixed temperature mode



Fixed temperature mode is a manual mode where the temperature can be changed directly, rather than following a preset schedule.

- In fixed temperature mode, the storage heater maintains a fixed room temperature until instructed otherwise.
- Easily adjust the target temperature via the WiFi app or the control panel.
- Activate a boost for temporary changes (section 4-3-4)

### To change the set temperature


To change the operating mode, refer to section 4-3 on page 11

DEVICE TYPE
<div style="border: 1px solid black; padding: 2px; display: inline-block;">                     FIXED TEMPERATURE ✓                 </div>
WEEKLY SCHEDULE

1. While in heating mode, use **+** and **-** to select your desired temperature
2. Press **Save** to confirm
  - The heater will enter the boost wizard, displaying possible durations for the new temperature
3. Select **ALWAYS** to permanently change the temperature
4. Press **OK** to confirm

Weekly schedule mode is the default operating mode of the storage heater. To change to fixed temperature mode, refer to section 4-3 on page 11.

### 4-3-3 | Weekly schedule mode




Adjust preset temperatures via the settings menu. (section 4-6-1, page 14)

In weekly schedule mode the device follows a 24/7 program, which can be adjusted via the settings menu.

- The schedule consists of three preset temperatures which can be assigned to each hour.
- The control panel display highlights the current hourly period, with the preset temperatures represented by the number of squares.
  - **Comfort:** 3 squares
  - **Eco:** 2 squares
  - **Anti-frost:** 1 square.

Weekly schedule mode is the default operating mode of the storage heater. To change the operating mode, refer to section 4-3 on page 11.

### 4-3-4 | Boost mode



Boost mode is used to temporarily override the current temperature.

- Enhance both fixed temperature and weekly schedule modes
- Cannot be used while in OFF mode

After the boost ends, the heater will return to the current scheduled temperature, or previous fixed temperature, depending on the mode.

### To initiate a boost

**Always** is only available as a boost duration when using the heater in manual (fixed) mode.

1. Press **+** or **-** while in heating mode to set up a boost 📌 period
2. Use **+** or **-** to select your desired temperature
3. Press **Save** to confirm
4. Use **+** or **-** to set the boost duration:
  - 1 to 5 hours
  - all day
  - always
5. Press **OK** to confirm.

### 4-4 | Device pairing

When using the heater without WiFi, all functions are available via the device control panel

The Ecostrad Magma HHR must be paired with the SmartBox if WiFi functionality is desired. WiFi control is available via the SmartControl app.



<https://ecostrad.com/magma-app/>

#### To pair the SmartBox to the app


1. In the app, press the menu at the top right of the home screen.
2. Press **Add new home**
3. Follow the instructions on the app to set your home name and time zone.
4. Press SmartBox when asked what your device looks like.
5. Connect your SmartBox to ethernet and power.
6. Press the sync button on the front of the SmartBox to put it into pairing mode.
7. The app will begin to search and find your SmartBox.
8. If needed, you can press **Next** to input the device ID code manually. You can also select **Back** to restart the search for your device.
9. Press **Start Search** on the app.
10. The heater will appear on the app, and **Device correctly linked** will display on the heater.

#### To pair the device with the SmartBox



1. In the app, press **Install** on the bottom of the home screen
2. Press **Storage Heater**
3. Press and hold (⏻) for 5 seconds on the storage heater to put the heater into pairing mode.
4. Press **Start Search** on the app.
5. The heater will appear on the app, and **Device correctly linked** will display on the heater.

### 4-5 | Keypad lock




The device keypad can be locked to prevent accidental changes.

Press and hold + and - together for 3 seconds to lock or unlock the keypad

- Buttons on the keypad will not be able to be pressed
- The WiFi app will still be able to change the temperature

## 4-6 | Device settings

### To enter the device settings menu



1. Press and hold **Menu** for 5 seconds
  - The settings menu will appear
2. Use **+** and **-** to navigate
3. Press **OK** to select an option
4. Press **Save** to confirm and go back

### 4-6-1 | Temperature settings

#### Default presets

Comfort 19.5 °C  
Eco 17 °C  
Frost 5 °C

In the **temperature settings** menu, the preset temperatures can be adjusted.




Figure 3 | Preset temperatures: comfort, eco, and anti-frost

- Preset temperatures are used in the weekly program
- Presets can be set to any temperature from 5 °C to 30 °C

### To change a preset temperature

#### Range:

5 °C to 30 °C

Comfort > Eco  
Eco > Anti-Frost

1. Press and hold **Menu** for 5 seconds
  - The settings menu will appear
2. Select **TEMPERATURES**
3. Select the preset you wish to change
4. Use **+** and **-** to adjust to your desired temperature
5. Press **OK** to confirm and go back
6. Repeat from step 3 to change an additional temperature preset

### 4-6-2 | Time & date settings

If using the WiFi application, the device time will sync with your phone.

In the **time and date** menu, the date and the time can be adjusted.

The clock can be set to display time in 24-hour or 12-hour format.




Figure 4 | Setting the time and date


### To set the time and date

1. Press and hold **Menu** for 5 seconds
  - The settings menu will appear
2. Select **TIME & DATE**
3. Use **+**, **—** and **OK** to select and change the **TIME**, **DATE**, or **TIME FORMAT**
4. Press **Save** to confirm and go back

### 4-6-3 | Program settings

In the **program** menu, the 24/7 schedule can be adjusted. Each day can be programmed separately, or the schedules can be copied across days.

#### To program the heater



1. Press and hold **Menu** for 5 seconds
  - The settings menu will appear
2. Select **PROGRAM**
3. Select the weekday you wish to program with **+**, **—** and **OK**
4. Press **OK** to select **EDIT**
5. Use **+** and **—** to highlight the hourly period that you wish to change
6. Press **OK** to adjust the temperature preset
  - Comfort: 3 squares
  - Eco: 2 squares
  - Anti-Frost: 1 square
7. Repeat from step 5 to assign preset temperatures to each hour
8. Once satisfied with the program for the current day, press **Save**

#### To copy a daily program to a different weekday




Figure 5 |  
Copy a program


1. Press and hold **Menu** for 5 seconds
  - The settings menu will appear
2. Select **PROGRAM**
3. Select the weekday with the program you wish to copy with **+**, **—** and **OK**
4. Select **COPY** with **+**, **—** and **OK**
  - The screen will show a checklist of weekdays
5. Use **+**, **—** and **OK** to add a tick mark the weekday(s) you wish to overwrite with the program
6. Press **Save**

### 4-6-4 | Device type

Use the **device type** setting to change the operation mode of the heater between fixed temperature and weekly schedule modes.

The weekly schedule operation mode is recommended for optimal energy savings and accuracy of charging times.

#### To select the preferred heating mode



1. Hold **Menu** down to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **DEVICE TYPE**
4. Select your preferred heating mode
  - **FIXED TEMPERATURE**: the target temperature is set manually
  - **WEEKLY SCHEDULE**: the heater follows a 24/7 schedule
5. Press **OK** to confirm

#### Fixed temperature mode

Fixed temperature mode is a manual operation mode

In fixed temperature mode, the radiator will maintain the set temperature indefinitely.

- The target temperature will only change if manually adjusted
- Boost mode allows for both temporary and permanent changes in temperature
- The radiator will charge during the off-peak period to accommodate the set temperature for the following day
- If the temperature is adjusted often, the radiator may run out of charge early or have an excess of charge at the end of the peak period


#### Weekly schedule mode

Weekly schedule mode is a 24/7 program operation mode

In weekly schedule mode, the radiator will follow a set 24/7 schedule.

- The radiator will charge during the off-peak period to accommodate the schedule for the following day
- The weekly schedule is the default operation mode, as the predictable schedule allows the heater to more accurately and efficiently charge
- In the case where frequent or regular adjustments in temperature are required, the weekly schedule mode is recommended
- Boost mode allows for temporary, timed changes in temperature


### 4-6-5 | Frost protection



The **frost protection** function can be enabled or disabled.

- When enabled, the heater will ensure that the room temperature never drops below 3 °C, even while the heater is in OFF mode
  - While in OFF mode, if frost protection is enabled, the display will indicate the frost protection temperature on the screen
- By default, frost protection is off

#### To enable or disable frost protection




1. Hold **Menu** down to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **FROST PROT.**
4. Select **DISABLED** or **ENABLED**

### 4-6-6 | Program resolution

Use **program resolution** to select whether the schedule can be set in hourly or half-hourly segments.

#### To select the program resolution



1. Hold **Menu** down to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **PROG. RESOL.**
4. Select **ONE HOUR** or **HALF HOUR**

### 4-6-7 | Charge configuration

The **charge configuration** is split into 2 subcategories:

#### Resistor configuration

The heating element can be enabled or disabled for peak and/or off-peak hours

The resistor configuration setting enables or disables the top-up heating element. Allowing the top-up heating element to work during peak hours means the energy will be charged at a higher rate, but it offers a safeguard in the case that the charge from the unit is depleted earlier than expected.

- The top-up heating element is a panel heater element outside of the storage heater's core. It can be used to heat the air in the room directly, providing quick heat and temperature correction.
- The top-up heating element only engages if the stored heat is not sufficient to heat the space to the desired temperature

## Manual Operation

### Available periods include

**Peak only** allows the storage heater to keep your room warm even if it runs out of charge early.

<b>Disabled</b>	Top-up heat is never used
<b>Peak &amp; Off-peak</b>	Top-up heat is used in both off-peak and peak intervals. Not recommended.
<b>Off-peak only</b>	Top-up heat is used only in off-peak intervals (during the charging schedule). Not recommended.
<b>Peak only</b>	Top-up heat is used only during the peak interval (outside of the charging schedule). This is the default setting.

### To set the resistor configuration

<b>ADVANCED</b>
▲ DEVICE TYPE FROST PROT. PROG. RESOL. CHARGE CONF. ▼
<b>RESISTOR CONFIG</b>
DISABLED PEAK & OFF-PEAK OFF-PEAK ONLY PEAK ONLY ✓

1. Hold **Menu** down for 5 seconds to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **CHARGE CONF.**
4. Select **RESISTOR CONFIG**
5. Select the desired period to enable the top-up heating element
6. Press **Save**

### Period schedule

The **period schedule** is used to schedule which times and days that the storage heater is permitted to charge.

Two daily charge periods are available

- The storage heater charges during scheduled off-peak periods, on scheduled days only.
- When using your storage heaters with a time of use tariff, ensure that the off-peak period(s) are matched to the period(s) specified by your tariff and that the time and date have been configured accurately.

### To set the period schedule

<b>CHARGE CONF.</b>
RESISTOR CONFIG PERIOD SCHEDULE
<b>PERIODS SCHEDULE</b>
CHARG. PERIODS CHARG. DAYS
<b>CHARGE PERIODS</b>
Start    End PERIOD 1: 23:00 08:00 PERIOD 2:

1. Hold **Menu** down for 5 seconds to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **CHARGE CONF.**
4. Select **PERIOD SCHEDULE**
5. Select **CHARG. PERIODS**
6. Select the period you wish to schedule
7. Select the start time of the period
8. Select the end time of the period
9. Press **Save**
10. Repeat from step 6 to configure the start and end times for a second period (optional)

## Manual Operation

### To set the charging days

CHARGE DAYS						
Set charging periods on:						
Mo	Tu	We	Th	Fr	Sa	Su
<input checked="" type="checkbox"/>						
▲						
						OK

1. Hold **Menu** down for 5 seconds to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **CHARGE CONF.**
4. Select **PERIOD SCHEDULE**
5. Select **CHARG. DAYS**
6. Add a tick mark to the days the radiator is allowed to charge on
7. Press **Save**

### 4-6-8 | Units

Default unit of temperature is °C

The **units** setting allows the user to select the desired unit of temperature. Celsius (°C) and Fahrenheit (°F) are both available.

### To change the display units

UNITS	
CELSIUS	✓
FAHRENHEIT	

1. Hold **Menu** down for 5 seconds to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **UNITS**
4. Select **CELSIUS** or **FAHRENHEIT**
5. Press **Save**

### 4-6-9 | Display settings

The **display** settings allows the user to configure the backlight timeout, brightness, and style of the display.

<b>Time ON</b>	Backlight timeout duration
<b>Brightness ON</b>	Screen brightness level when the backlight is active
<b>Brightness OFF</b>	Screen brightness level when the backlight is inactive
<b>Style</b>	Display colours of the screen and characters

DEVICE TYPE
FIXED TEMPERATURE
WEEKLY SCHEDULE ✓

Figure 6 | Display styles from left to right: Light B/W (default), Dark W/B, Light/Color

## Manual Operation

### To configure the display

1. Hold **Menu** down for 5 seconds to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **DISPLAY**
4. Use **+**, **-** and **OK** to adjust the display settings
5. Press **Save** to confirm and go back





Figure 7 | Configuring the display settings

### 4-6-10 | Beep

The **beep** can be enabled or disabled

- When enabled, the heater will beep whenever a button is pressed

#### To enable or disable the beep



1. Hold **Menu** down to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **BEEP**
4. Select **DISABLED** or **ENABLED**

### 4-6-11 | Control type

The Magma HHR is equipped with two different control types for the heating cycle; Hysteresis (HYST) and Proportional Integral Derivative (PID) control.

**PID 15 min** (default)

**PID 30 min**

**Hysteresis 0.25 °C** Heat to set temperature +/- 0.25 °C

**Hysteresis 0.35 °C** Heat to set temperature +/- 0.35 °C

**Hysteresis 0.50 °C** Heat to set temperature +/- 0.50 °C

**Hysteresis 0.75 °C** Heat to set temperature +/- 0.75 °C

## Manual Operation

### To change the control type

CONTROL TYPE	
▲	HYST 0.35
	HYST 0.50
	HYST 0.75
	PID15 ✓
▼	

1. Hold **Menu** down for 5 seconds to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **CONTROL TYPE**
4. Select the desired control type.
5. Press **Save**.

### Hysteresis (HYST)

**Hysteresis control** simply releases heat until the room temperature is a specific value above the set temperature, then turns off the heat until the room temperature falls to a specific value below the room temperature.

For example, a heater at HYST 0.25 °C set to heat to 20 °C would heat until the room temperature is 20.25 °C and then stop heating until the room temperature drops to 19.75 °C

### Proportional Integral Derivative (PID)

**PID control** improves the accuracy of hysteresis by analysing the speed at which the temperature is changing, and adjusting the amount of heat released to ensure that the desired temperature is maintained.

Choosing a 15 minute PID will keep the room temperature closer to the target temperature. Choosing a 30 minute PID will allow for a slightly greater variation in temperature.

## 4-6-12 | Open window detection

Press any button to cancel the open window detection period

Open window detection can be enabled or disabled via the advanced settings menu. By default, this feature is disabled.

- When enabled, the heater will stop releasing heat if it detects a sudden drop of at least 1.2 °C over 10 minutes.
- The radiator will return to its normal heat cycle if the user presses any button, or if the room temperature increases by 0.3 °C over 10 minutes.

### To enable or disable open window detection

OPEN WINDOW	
	DISABLED ✓
	ENABLED

1. Hold **Menu** down to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **OPEN WINDOW**
4. Select **DISABLED** or **ENABLED**
5. Press **Save**

### 4-6-13 | Smart start

Smart start only works in weekly schedule mode

If using more than one storage heater to heat a room, ensure that the smart start settings match.

Smart start is a type of adaptive start that intelligently heats a room to reach the scheduled temperature at the scheduled time. Smart start can be enabled or disabled via the advanced settings menu.

- By default, this feature is disabled.
- When enabled, the heater will dynamically heat the room with a target of reaching the set temperature at the scheduled time.
- When disabled, the heater will wait until the scheduled time to make any changes to the heat.

For example, if the heater is set to increase temperature from 18 °C to 20 °C at 3:00, then the heater will calculate how long it will take to increase the temperature. At 2:45, it will begin to heat the room with the expectation that the room temperature will reach 20 °C at 3:00, when the scheduled temperature change is to take place.

#### To enable or disable smart start

SMART START	
DISABLED	✓
ENABLED	

1. Hold **Menu** down to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **SMART START**
4. Select **DISABLED** or **ENABLED**
5. Press **Save**

### 4-6-14 | Offset temperature

Use the offset to calibrate the temperature sensor

The offset option allows the user to calibrate the room temperature sensor.

- Due to the positioning of the heater on the wall, the room temperature sensor could be located in a hot or cool spot, resulting in an inaccurate heat output.
- The temperature reading can be offset by an error margin of up to 3 °C in steps of 0.1 °C.

#### To adjust the temperature offset

OFFSET	
OFFSET:	+ 0.0 °C
TEMP:	24.8 °C

1. Hold **Menu** down to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **OFFSET**
4. Use **+**, **-** and **OK** to adjust the offset value
5. Press **Save**

### 4-6-15 | Parameters



#### WARNING


The parameters option is for service engineer use only! Never change parameters without guidance from the manufacturer.

Improper parameter changes could lead to malfunction and injury.

### 4-6-16 | Language

The language option allows the user to choose between English, German, or Spanish.

#### To change the language



1. Hold **Menu** down to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **LANGUAGE**
4. Select the desired operating language
5. Press **Save**


### 4-6-17 | Reset

#### WARNING

When the device is reset, all recorded information, including the link to the Smartbox and any initial setup by your installer, is lost.

All programs and all settings are returned to the factory default.

#### To restore the device to factory default



1. Hold **Menu** down to enter the settings menu
  - Use **+**, **-** and **OK** to navigate the menu
2. Select **ADVANCED**
3. Select **RESET**
4. Select **YES** to return the device to factory default

## 5 | Warranty

The Ecostrad Magma HHR German Storage Heater carries a 10-year guarantee on the body and a 2-year guarantee on electrical components.

### **What does the warranty cover?**

Within the stated period, starting from the date the customer receives their unit, Ecostrad guarantee to repair or replace the unit where a fault is due to defects in materials or manufacturing.

### **What does the warranty NOT cover?**

The warranty does not cover any defect arising from damage, negligence, usage outside the product's intended purpose or fair wear and tear. The warranty is only valid when the unit has been used at the specified supply voltage, and in accordance with all conditions specified in this manual. The warranty will be void if the heater has been covered, tampered with, or if the ratings label has been removed.

The warranty does not cover failures and faults due to force majeure, accidental damage, mishandling, external impact, chemical agents or atmospheric phenomena, incorrect use of the device, the purchaser's faulty electrical installations, transporting the device or problems caused by the device being handled by persons not authorised by Ecostrad. If the unit has been installed, an invoice may be required to confirm the work was carried out by a qualified professional. Ecostrad cannot accept responsibility for damage, loss or injury caused by incorrect installation, maintenance, cleaning or covering the device.

### **How to claim**

The warranty is a contract with the original purchaser and does not transfer if the unit is re-sold, gifted or inherited.

Proof of purchase, including order number and order confirmation or invoice, will be required if a claim is made.

The warranty covers only the model of heater shown on the purchase invoice. The warranty covers the repair or replacement of the defective product only and Ecostrad shall have no liability for installation costs or consequential losses however incurred.

Claims must be made with the establishment where the device was purchased. This warranty does not affect the customer's consumer rights.

## 6 | Disposal



In accordance with WEEE Directive 2012/19/EU, the icon with the crossed-out waste bin on electrical or electronic equipment stipulates that this equipment must not be disposed of with household waste at the end of its life. You will find collection points for free return of waste electrical and electronic equipment in your vicinity. The addresses can be obtained from your local authority.

The separate collection of waste electrical and electronic equipment enables the re-use, recycling and other forms of recovery of waste equipment, and prevents any negative effects for the environment or human health caused by the disposal of hazardous substances potentially contained in the equipment.

For queries, contact:

### **The UK manufacturer**

Ecostrad Ltd.  
Unit 21 Ash Way  
Avenue C  
Thorp Arch Trading Estate  
Wetherby  
West Yorkshire  
LS23 7FR

<https://ecostrad.com>

### **The ROI Importer**

Ignition Heatco Ireland Limited  
Unit 282  
Block G  
Blanchardstown Corporate Park 2  
Dublin  
Republic of Ireland  
D15 R65X

