











RC Wave Plus – Programming via Keypad






Contents:




- Top Tips
- Keypad
- Initial Setup
- Mode
- Setting the Temperature
- Advanced Settings
- Programming

Top Tips






<p>Frost</p> 	<p>Frost mode acts as the radiator's standby mode.</p> <p>Press  to switch on.</p>	<p>Sleep</p> 	<p>The screen sleeps when not in use, displaying the icon of the current mode. This is to save power. Press any key to wake up.</p>
<p>Time Out</p> 	<p>Keyboard is locked when it displays this symbol.</p> <p>Press  and  together to unlock.</p>	<p>App Connection</p> 	<p>When you press , radiator will go into app connection mode. The radiator will stay in this mode for 10 seconds before returning to previous screen.</p>
<p align="center"> Be aware, all menus time out after 18 seconds </p>			


Keypad

		<ul style="list-style-type: none"> • Toggle Manual / Auto • Decrease (in menus)
		<ul style="list-style-type: none"> • Toggle Comfort / Economy / Anti-Frost • Increase (in menus)
		<ul style="list-style-type: none"> • Bluetooth Connect • Previous (in menus)
		<ul style="list-style-type: none"> • Frost • Next (in menus)
	<p>19 °C</p>	<ul style="list-style-type: none"> • Actual Temperature
	<p>28 °C</p>	<ul style="list-style-type: none"> • Set Temperature

	<p>Manual</p>		<p>Comfort</p>
	<p>Automatic</p>		<p>Economy</p>
	<p>Connected to App</p>		<p>Anti-Freeze</p>
	<p>Disconnected from App</p>		<p>Turn Off</p>
	<p>Heating</p>		<p>Open Window</p>
	<p>Boost</p>		<p>Adaptive Start</p>
	<p>Keypad Locked</p>		

Initial Setup

- Plug in.
- Press the ON/OFF switch on the back of the unit.
- Use arrow keys  **M** and  **B** to set day of week. (1 = Monday). Press  to confirm.
- Use arrows to set hours. Press .
- Use arrows to set minutes. Press .














Mode

- Press  **M** until you see the  symbol.
- Press  **B** to cycle between modes:
 - Comfort 
 - Economy 
 - Anti-frost 













Setting the Temperature

- Start on the Manual  or Auto  screen.
- Hold down  **M**.
- Economy  temperature will display. Use  **M** and  **B** to adjust. Press  to confirm.
- Comfort  temperature will display. Use  **M** and  **B** to adjust. Press  to confirm.

























Advanced Settings

- Press  until you see the anti-freeze screen.
- Hold down .
- Toggle  open window detection feature – use  **M** and  **B** to switch between On and Off.
- Press  to confirm.
- Toggle  adaptive start feature – use  **M** and  **B** to switch between On and Off.
- Press  to confirm.



Programming

- Toggle  until you see the  symbol.
- Hold down 
- Set day – use  and  to adjust, press  to confirm
- Set time – use  and  to adjust, press  to confirm
- Select which day you want to program – use  and  to adjust, press  to confirm
- Assign programming modes to hours:
 - Use  and  to cycle through the hours
 - Press  to change mode (colours of mode symbol will invert)
 - Use  and  to cycle through modes (Comfort, Economy, Anti-Freeze, Turn Off)
 - Press  to confirm mode.
 - Continue through the hours and days. The display will automatically move onto the next day. However, you can skip to another day by pressing  and selecting the day using the  and  keys. Press  to confirm.
- When you've finished programming, wait eighteen seconds for the menu to automatically close.

